

TurboTemp 2™

INSTRUCTIONS

RxOnly

PRODUCT DESCRIPTION

TurboTemp 2™ is a unique 4:1, syringeable bis-acryl composite for temporary restorations. TurboTemp 2 is fast and accurate, especially when used in conjunction with a quality vinyl polysiloxane impression material such as Start VPS (available from Danville Materials).

INDICATIONS

TurboTemp is a temporary crown and bridge material used for temporary restorations. TurboTemp 2 is designed as a syringeable acrylic provisional composite used for fast temporary crown and bridge placement.

PRECAUTIONS

1. TurboTemp 2 contains methacrylate monomers which can cause allergic reactions in susceptible individuals. Avoid contact between uncured product and skin, oral soft tissues or eyes. Do not take internally. Consult MSDS for more information.
2. Use as directed. This product is intended for use by dental practitioners only. Wear appropriate personal protective equipment.
3. TurboTemp 2 will adhesively bond to most dental adhesives and the air inhibited layer of fresh resin-based restoratives, making provisional removal for trimming difficult.
4. Contact with Eugenol containing products may interfere with the hardening of TurboTemp 2.
5. TurboTemp 2 **MUST BE REMOVED FROM THE PATIENT PRIOR TO 30 DAYS.**

TURBOTEMP 2 KIT

TurboTemp 2 comes in a 76 gm automix cartridge. Ten waste-saver tips are included per kit.

TurboTemp 2 cartridges are designed to fit on a new style automix gun.

It is important not to remove the cap on the cartridge until use. After use, leave the used tip on the cartridge. The hardened resin in the tip acts as a cap until the next use.

IMMEDIATELY PRIOR TO USE

Remove cap and eject about a pea size quantity of material out of the bare cartridge end. Eject slowly until steady flow exudes from both compartments. Wipe off the end (without cross mixing) and install the mixing tip.

BEFORE THE PREP

Make initial impression. Place some flexible vinyl polysiloxane (Start VPS Monophase recommended) on a posterior type bite tray and have patient close. Stiff heavy body materials must be avoided, as once removed, they do not go back well into undercuts. Alginate will also serve as a less satisfactory alternative.

An inexpensive bite tray is recommended for the initial impression. The small bite tray requires less impression material.

PREP AND FINAL IMPRESSION

Cut preparation. Take a final impression for the lab. Use a triple tray. Dual viscosity vinyl polysiloxane impression materials are recommended.

AFTER THE PREP

Once the prep and the lab impression have been completed, you are ready to make the temporary. Working time is only 30 to 40 seconds. Set time is 1-1/2 minutes after placement in mouth and full hardness is 3 to 4 minutes. Inject TurboTemp 2 into the prep areas of the preliminary impression. Use care to avoid trapping air bubbles. Have patient close on tray. Choose cementation technique A or B.

A. Cementation Method (Recommended Technique)

1. Remove the tray 1-3/4 to 2 minutes after the mix was injected. The temporary will be retained in the tray and will be slightly flexible. Break off the excess material around the temp while it is still in the impression. This excess should be thin and flexible and can be trimmed easily with an amalgam carver.
2. Immediately reset the temp in the mouth and wait 1 or 2 more minutes for the completion of cure.
3. Remove again, wait 4-5 minutes, and pop the temp out of impression.
4. Trim margins with a diamond (it is now rigid).
5. Cement in place, using a non-eugenol temporary cement.

B. Non-Cementation Method

1. Leave TurboTemp 2 in the mouth during the initial insertion for 2 ½ minutes. It will shrink to fit. It is recommended to cut an escape route in the facial surface of the impression. This will allow excess TurboTemp 2 to escape, thereby reducing flashing.

TurboTemp 2™

INSTRUCTIONS

RxOnly

PRODUCT DESCRIPTION

TurboTemp 2™ is a unique 4:1, syringeable bis-acryl composite for temporary restorations. TurboTemp 2 is fast and accurate, especially when used in conjunction with a quality vinyl polysiloxane impression material such as Start VPS (available from Danville Materials).

INDICATIONS

TurboTemp is a temporary crown and bridge material used for temporary restorations. TurboTemp 2 is designed as a syringeable acrylic provisional composite used for fast temporary crown and bridge placement.

PRECAUTIONS

1. TurboTemp 2 contains methacrylate monomers which can cause allergic reactions in susceptible individuals. Avoid contact between uncured product and skin, oral soft tissues or eyes. Do not take internally. Consult MSDS for more information.
2. Use as directed. This product is intended for use by dental practitioners only. Wear appropriate personal protective equipment.
3. TurboTemp 2 will adhesively bond to most dental adhesives and the air inhibited layer of fresh resin-based restoratives, making provisional removal for trimming difficult.
4. Contact with Eugenol containing products may interfere with the hardening of TurboTemp 2.
5. TurboTemp 2 **MUST BE REMOVED FROM THE PATIENT PRIOR TO 30 DAYS.**

TURBOTEMP 2 KIT

TurboTemp 2 comes in a 76 gm automix cartridge. Ten waste-saver tips are included per kit.

TurboTemp 2 cartridges are designed to fit on a new style automix gun.

It is important not to remove the cap on the cartridge until use. After use, leave the used tip on the cartridge. The hardened resin in the tip acts as a cap until the next use.

IMMEDIATELY PRIOR TO USE

Remove cap and eject about a pea size quantity of material out of the bare cartridge end. Eject slowly until steady flow exudes from both compartments. Wipe off the end (without cross mixing) and install the mixing tip.

BEFORE THE PREP

Make initial impression. Place some flexible vinyl polysiloxane (Start VPS Monophase recommended) on a posterior type bite tray and have patient close. Stiff heavy body materials must be avoided, as once removed, they do not go back well into undercuts. Alginate will also serve as a less satisfactory alternative.

An inexpensive bite tray is recommended for the initial impression. The small bite tray requires less impression material.

PREP AND FINAL IMPRESSION

Cut preparation. Take a final impression for the lab. Use a triple tray. Dual viscosity vinyl polysiloxane impression materials are recommended.

AFTER THE PREP

Once the prep and the lab impression have been completed, you are ready to make the temporary. Working time is only 30 to 40 seconds. Set time is 1-1/2 minutes after placement in mouth and full hardness is 3 to 4 minutes. Inject TurboTemp 2 into the prep areas of the preliminary impression. Use care to avoid trapping air bubbles. Have patient close on tray. Choose cementation technique A or B.

A. Cementation Method (Recommended Technique)

1. Remove the tray 1-3/4 to 2 minutes after the mix was injected. The temporary will be retained in the tray and will be slightly flexible. Break off the excess material around the temp while it is still in the impression. This excess should be thin and flexible and can be trimmed easily with an amalgam carver.
2. Immediately reset the temp in the mouth and wait 1 or 2 more minutes for the completion of cure.
3. Remove again, wait 4-5 minutes, and pop the temp out of impression.
4. Trim margins with a diamond (it is now rigid).
5. Cement in place, using a non-eugenol temporary cement.

B. Non-Cementation Method

1. Leave TurboTemp 2 in the mouth during the initial insertion for 2 ½ minutes. It will shrink to fit. It is recommended to cut an escape route in the facial surface of the impression. This will allow excess TurboTemp 2 to escape, thereby reducing flashing.

- Remove impression from mouth; the temporary should remain in the mouth.
- Trim excess with the scalpel blade or a diamond bur if necessary.

Note: Some non-cemented TurboTemp 2 restorations may turn dark after two weeks. To avoid this, either place permanent restoration within two weeks or cement the temporary restoration.

TurboTemp 2 bridge fabrication:

Three units is the recommended maximum span. To add strength to the proximals of posteriors, the connector areas should be modified to add bulk, prior to taking the preliminary impression. In the posterior, both buccal and lingual can be modified. In the anterior, most of the modification would be done on the lingual to preserve esthetics. The preferred block-out material is Ultradent Blue Bolckout, but soft wax can also be used.

Reinforcement can also be used in addition:

Take the preliminary impression. Then place a piece of Ribbond or some other fibers, from mesial to distal, using cured flowable composite to hold it on preps. The entire piece of reinforcement should be infused with flowable composite. A figure 8 configuration might be considered. No bonding is used so that the reinforcement will be retrievable with the temporary restoration. In the usual manner, form the TurboTemp 2 over the reinforcement. Do not disturb the oxygen inhibited outer layer on the flowable so the TurboTemp 2 will adhere directly to it.

Troubleshooting

- When starting with a new cartridge, discard the first pea size amount dispensed through the mixing tip to ensure even mixing.
- Do not remove the mixing tip after each use. Wait until ready to use it again, then install new tip. This will prevent catalyst contamination possibly resulting in a plug.
- Mount the mixing tip in proper alignment. Note that the tips are notched to indicate the proper alignment on the cartridge. By forcing the tip, it can be mounted backwards, resulting in non-setting mixes. (The two sides of the mixing tip have different size bores.)
- A slightly gummy air inhibited layer will remain on the hardened surface of the temporary. This layer allows bubble and margin defects to be minimized by directly bonding with a flowable composite such as StartFlow. The layer is easily removed with ethyl alcohol.
- Exposure to temperatures below 74°F will extend the setting time of TurboTemp 2. Set times are based on room temperature material. Refrigeration greatly retards set times.
- Normally there is no need for occlusal adjustments if vinyl polysiloxane is used.
- Before placing a new mix tip, extrude a small amount of material to insure both sides are flowing. Waste a pea size amount of material immediately before use to ensure a full mix.

Storage

Store at or below 75°F (24°C). Use at room temperature.

Definitions of Symbols

The following symbols may appear on the product packaging or labeling.

Symbol	Definition	Symbol	Definition
	Reference number		Lot number
	Use by		Upper limit of temperature
	Caution: Federal law restricts this device to sale by or on the order of a dentist.		Keep away from sunlight
	Manufacturer		Consult instructions for use

Danville Materials
a Zest Anchors, LLC company
2875 Loker Avenue East
Carlsbad, CA 92010 USA
(1)760-743-7744

www.zestdent.com

ZEST DENTAL
SOLUTIONS

90346 REV J

- Remove impression from mouth; the temporary should remain in the mouth.
- Trim excess with the scalpel blade or a diamond bur if necessary.

Note: Some non-cemented TurboTemp 2 restorations may turn dark after two weeks. To avoid this, either place permanent restoration within two weeks or cement the temporary restoration.

TurboTemp 2 bridge fabrication:

Three units is the recommended maximum span. To add strength to the proximals of posteriors, the connector areas should be modified to add bulk, prior to taking the preliminary impression. In the posterior, both buccal and lingual can be modified. In the anterior, most of the modification would be done on the lingual to preserve esthetics. The preferred block-out material is Ultradent Blue Bolckout, but soft wax can also be used.

Reinforcement can also be used in addition:

Take the preliminary impression. Then place a piece of Ribbond or some other fibers, from mesial to distal, using cured flowable composite to hold it on preps. The entire piece of reinforcement should be infused with flowable composite. A figure 8 configuration might be considered. No bonding is used so that the reinforcement will be retrievable with the temporary restoration. In the usual manner, form the TurboTemp 2 over the reinforcement. Do not disturb the oxygen inhibited outer layer on the flowable so the TurboTemp 2 will adhere directly to it.

Troubleshooting

- When starting with a new cartridge, discard the first pea size amount dispensed through the mixing tip to ensure even mixing.
- Do not remove the mixing tip after each use. Wait until ready to use it again, then install new tip. This will prevent catalyst contamination possibly resulting in a plug.
- Mount the mixing tip in proper alignment. Note that the tips are notched to indicate the proper alignment on the cartridge. By forcing the tip, it can be mounted backwards, resulting in non-setting mixes. (The two sides of the mixing tip have different size bores.)
- A slightly gummy air inhibited layer will remain on the hardened surface of the temporary. This layer allows bubble and margin defects to be minimized by directly bonding with a flowable composite such as StartFlow. The layer is easily removed with ethyl alcohol.
- Exposure to temperatures below 74°F will extend the setting time of TurboTemp 2. Set times are based on room temperature material. Refrigeration greatly retards set times.
- Normally there is no need for occlusal adjustments if vinyl polysiloxane is used.
- Before placing a new mix tip, extrude a small amount of material to insure both sides are flowing. Waste a pea size amount of material immediately before use to ensure a full mix.

Storage

Store at or below 75°F (24°C). Use at room temperature.

Definitions of Symbols

The following symbols may appear on the product packaging or labeling.

Symbol	Definition	Symbol	Definition
	Reference number		Lot number
	Use by		Upper limit of temperature
	Caution: Federal law restricts this device to sale by or on the order of a dentist.		Keep away from sunlight
	Manufacturer		Consult instructions for use

Danville Materials
a Zest Anchors, LLC company
2875 Loker Avenue East
Carlsbad, CA 92010 USA
(1)760-743-7744

www.zestdent.com

ZEST DENTAL
SOLUTIONS

90346 REV J